

HITACHI Camera Accessories		KP-M1A, M2A, M3A	KP-M2R, KP-M3R	KP-M20 / M30	KP-E500, KP-DE500	KP-F30, F33, F37, F38, F80	KP-FB30SCL, KP-FBR30SCL	KP-FD30, FD30M	KP-FD30CL	KP-F30SCL, KP-FR30SCL	KP-F31SCL, KP-FR31SCL	KP-F39SCL, KP-FR39SCL	KP-F80SCL, KP-FR80SCL	KP-F32F, F83F, F140F	KP-FD32F, KP-FD140F	KP-F33GV, KP-FD33GV	KP-F83GV, KP-FD83GV	KP-F140GV, KP-FD140GV	KP-F100B, F100BCL	KP-F120, KP-F120C, KP-F120CL	KP-F120F	KP-FD140SCL, KP-FD500SCL	KP-F200CL	KP-F200SCL, KP-FR200SCL	KP-FD202SCL	KP-F230SCL, KP-FR230SCL	KP-F500SCL, KP-FR500SCL	KP-D20A, KP-D20B	KP-D590	KP-D531, D591	HV-D27A, 37A	HV-D30	HV-F22GV	HV-F22F, F31F	HV-F22CL, F31CL						
		Power Supplies	Junction Box	Level Converter	Junction Box	Cables	Remote Head	Camera Cables	Remote Control	Cables																															
45601-C1	R	R	R		R	R	x	R	R	R	R	R							R	R		R	R	R	R	R	R	R	x				x	x							
45601-C4	x	x			x	x		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x		x					x	x	x				
45601-C5	x	x	x		x				x					x	x					x	x	x														x	x	x			
45601-C6																																									
45601-C9	x	x	x		x																																				
45601-C15							x																																		
DV12-C1	R	R	R	x	R	R	x	R	R	R	R	R							R	R		R	R	R	R	R	R	R	x			x	x								
DV12-C4	x	x			x	x		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x		x					x	x	x				
DV12-C7																																									
JU-M1A	R	R			R					R	R	R							R	R		R	R	R	R	R	R														
JU-F30			R		R				R																																
JU-C20																																									
JU-Z2																																									
C201 KS	R	R	R		R	R				R	R	R	R						R	R		R	R	R	R	R	R	R													
C501 KS	R	R	R		R	R				R	R	R	R						R	R		R	R	R	R	R	R	R													
C102 KS	R	R	R		R	R				R	R	R	R						R	R		R	R	R	R	R	R	R													
C-501KAJ																																									
C-102KAJ																																									
C-201KAJ																																									
C9D232C-6																																									
C9D232CF-6																																									
C-152-RC2																																									
C-302-RC2																																									
C-602-RC2																																									
C-103-RC2																																									

R Junction Boxes require a camera cable and a C1 type power supply in order to power the camera.

O Remote Control Units and Level Converters require a cable to work with the camera.

x These items require no additional interface components.

